

INSTRUCTIONS

CAT. # 2CT32 TACHOMETER

RPM 0-3500.
FOR USE ON DISTRIBUTOR
or MAGNETO IGN.


! IMPORTANT !

This tach. uses the signal from the DIST./MAG.

Calibrated for 2 IMP. per/rev. (4 CYL.)

On some engines, reverse pin #2 and #5 for steady reading.

For lighting, order light kit # 186



Install the instrument in a 2-1/16 inch hole in convenient operating place. Use U clamp to hold in place to hold in place.

On the rear of the instrument there are connecting pins with corresponding numbers.

Use patch cable provided to connect the instrument to the appropriate power source.

Connect pin to point side of coil or "P" lead on mag. (tach wire, kill switch). Connect pin #5 to engine ground. Reverse pin #2 and #5 on some engines for steady reading.

See illustration.

Patch cable may be lengthened without affecting accuracy of the unit. Using 20-22 gauge wire is recommended. Route wires away from hot manifolds and pipes. Support with wire ties every 12-15 inches. Use rubber grommets when going through metal.

WARRANTY

WESTACH INSTRUMENTS are made with the highest quality material and workmanship. With reasonable care, instruments will give long and satisfactory service. WESTACH INSTRUMENTS are guaranteed against defective material and workmanship for 12 months from the manufacturing date. For complete details go to www.westach.com



WESTBERG MFG. INC.
www.westach.com